


ASSEMBLY INSTRUCTION

MODEL : ELYSSE (3 SEATER SOFA)

Read this instruction carefully. Refer hardware and furniture parts are complete before assembling. Place all on a clean and flat soft surface to prevent scratches. Refer steps provided as assembling guide.

HARDWARE LIST

| NO | DESCRIPTION | QTY | Total |
|----|-------------------------------|--------|--------|
| A | Wood Leg with metal plate - A | 4 PCS | 4 PCS |
| B | Middle Leg - B | 1 PCS | 1 PCS |
| C | Screw M8 x 25mm | 12 PCS | 12 PCS |
| D | Flat Washer 5/16" | 12 PCS | 12 PCS |
| E | M5 Allen Key | 1 PCS | 1 PCS |



3 SEATER SOFA

Step 1 : Use Allen key (E) and drive the screw (C) and flat washer (D) to attach to the timber leg with metal plate. (A). Repeat step for all four legs.

Step 2 : Screw the middle Leg (B) and attach to the middle of the sofa as shown in the image.

