




MONTEGO COFFEE TABLE



PRE-ASSEMBLY PREPARATION

BEFORE YOU START

1. Choose a clean, level, spacious assembly area.
2. Avoid hard surfaces that may damage the product.
3. Take care when lifting. Product should be assembled as near as possible to the point of use
4. Check and ensure you have all required contents for complete assembly.
5. Always read the assembly instructions carefully before beginning.
6. The packaging and contents can be a choking hazard, therefore keep out of reach of small children at all time.
7. Do not over tighten bolts as this may damage the thread.











ALLOW 30 MINUTES
FOR ASSEMBLY



2 PEOPLE REQUIRED
FOR ASSEMBLY

COMPONENTS / HARDWARE


A  2PCS	B  1PC	C  1PC	D  1PC
E  M6*15 8PCS	F  M6*25 4PCS	G  12PCS	H  1PC

IMPORTANT:

To ensure legs are even, some steps require that bolts are not to be completely tightened until all parts are joined. Once all parts are joined, flip furniture over, ensure all legs are even, then proceed to tighten bolts. Read each step carefully before completing assembly.


STEP 1:

- ALIGN HOLES IN PART(A) OVER THREADS IN PART (B).
- ATTACH PART (A) TO PART (B) USING BOLTS AND WASHERS AS SHOWN BELOW.
- BE CAREFUL NOT TO OVER TIGHTEN AS THIS MAY DAMAGE THREADS.




STEP 2:

- ALIGN HOLES IN PART (C) OVER THREADS IN PART (A).
- ATTACH PART (C) TO PART (A) USING BOLTS AND WASHERS AS SHOWN BELOW.
- BE CAREFUL NOT TO OVER TIGHTEN AS THIS MAY DAMAGE THREADS.



STEP 1:

- PUT GLASS (D) ON TABLE TOP.
- YOUR TABLE IS READY FOR USE.



CARE AND MAINTENANCE

GLASS

- If the glass is chipped or broken, stop using the product and consult the place of purchase
- Do not drop, drag or strike glass
- Do not sit or stand upon the glass surfaces
- Do not place very hot or cold items on the glass unless adequately thick table mats are used to prevent such items coming in contact with the glass
- Do not place heavy objects on glass
- Avoid scratching the glass or using as a chopping surface
- Do not strike the glass with hard or pointed items
- When cleaning the glass panels, use a damp cloth with washing up liquid or soft soap if necessary. Do not use washing powders or any other substances containing abrasives that may potentially scratch the glass

CHAIRS AND STOOLS

- **Do not:**
 - Use chair/stool as a ladder
 - Climb on the chair/stool
 - Stand on the foot-rest of the chair, as this could lead to the stool becoming unbalanced and overturning

WICKER AND TEXTILENE

- Our Resin wicker and Textilene furniture requires very little maintenance to keep it looking like new.
- For daily care and spills, simply wipe clean using a soft, dry cloth.
- To remove dirt and grime, simply rinse with fresh water or periodically clean using a sponge and mild detergent solution as required.
- To protect the finish, avoid the use of abrasive chemicals, harsh cleaners, rough cleaning pads and polishes.

IN CASE OF DIRECT SUNLIGHT

- To guard against fading, any Outdoor Furniture exposed to direct sunlight or the everyday elements, we recommend the use of outdoor furniture covers.
- For cushions exposed to direct sunlight or the everyday elements, we recommend storage of cushions when not in use.