


CATANIA 3 SEATER

ASSEMBLY INSTRUCTION




These instructions must be used to ease the assembly of your furniture . Please ensure that you have all the components before assembly . Remember to place the part on a carpeted floor or blanket in order them from damage while you assemble .

Components

A Seater Frame  01 pc	B Leg Frame  01 pc	C Left Leg  01 pc
D Right Leg  01 pc	E Support Leg  02 pcs	F Bolt M6 X 100  04 pcs
G Bolt M6 X 60  02 pcs	H Bolt M6 X 40  06 pcs	I Bolt M6 X 25  04 pcs
J Cross Dowel M6 X 15  06 pcs	K Allen Key  01 pc	L Seat Cushion  03 pcs
M Back Cushion  03 pcs		


Step

1




Step

2




Step

3




Step

④




Step

⑤




Step

⑥



Step

⑦

**Finished**

CHARACTERISTICS OF TEAK

- Teak furniture is suitable for outdoor living. With regular maintenance, it can last for many years. Due to natural variations in the wood, each product and finish may vary slightly.
- When exposed to sun and rain, the color of teak will change to a silver-grey patina. This is part of the teak's life cycle.
- We support responsible timber sourcing and aim to work harmoniously with the environment. We are certified by the Forest Stewardship Council® (FSC), which promotes environmentally, socially, and economically responsible forest management.

MAINTENANCE

- Use a dry, clean cloth to dust furniture weekly.
- For spot cleaning, spray off debris with a hose and brush off dirt or debris with a soft-bristle brush. Dry with a soft cloth.
- New teak may have oil surfacing that looks like water marks; these can be removed by gentle washing.
- For thorough cleaning, use Golden Care® Hardwood & Teak Cleaner. Clean furniture periodically and before storing.
- Additionally, consider using:
 - Golden Care® Teak Shield: Penetrates and protects teak and other hardwood furniture from water and stains, and helps protect against mould, mildew, and UV rays.
 - Golden Care® Teak Protector – Helps maintain the original colour of the teak longer.
- Avoid letting water stand on furniture surfaces and cushions.
- Protect furniture by covering or storing it when not in use for extended periods. Clean and dry furniture thoroughly before covering. Store cushions in a dry place if possible.
- Clean cushions thoroughly with Golden Care® Multi Surface Cleaner and Golden Care® Fabric Protector to maintain the new look and make the fabric repellent to dirt, water, and moisture.