


Finn 3 Seater Sofa: F34632KD-FK-3P2C

1


A X 4	E X 1
	
16.7CM(H)	
B X 1	
	
18.8CM(H)	
C X 4	
	
M10	
D X 4	
	
M10 x 18MM	



 X 4
 X 1
 X 4
 X 4
 X 1

The legs are located in the zipped compartment under the sofa


2



Finn Armchair: F34632KD-FK-1P

1

A X 4	C X 4
	
16.7CM(H)	M10 x 18MM
B X 4	D X 1
	
M10	



	• • • •	X 4
	• • • •	X 4
	• • • •	X 4
	• • • •	X 1

The legs are located in the zipped compartment under the sofa

2

