

E1213 User Manual

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment.


Before using, please read this operation manual thoroughly in order to understand the correct methods of usage, especially taking note of the section on safety, it is important. This manual should be kept on hand for easy reference. It is your guidance to a safe and efficient operation. Using the product correctly could prolong the life circle.

Caution


- Please use the original power supply provided by the manufacturer.
- To prevent you from burns or electric shock, the unit should never be left unattended when plugged in. Always unplug the unit when it is not in use.
- Children should not use this product without the supervision of the adult.
- Never operate the unit if it has a damaged power or plug.
- Please contact the store if it is not working properly, if it has been dropped or damaged, or if it has been immersed in water.
- Keep power cords away from heated surfaces and never use it if it has a damaged cord.
- Do not drop or insert anything into any of the opening of the unit.
- Liquids. Should not be spilled on the control panel.
- Indoor use only, do not put it into direct sunlight exposure.
- The unit contains no user-serviceable parts and open or disassembling any parts of it may cause an electric shock or injury.
- Persons with any of the below conditions or who are undergoing medical treatment should consult with their physicians before using the unit:
Pregnant women, People who have a pacemaker, defibrillator, or other personal medical devices prone to electronic interference.

Assemble illustration

Over view



3 seat recliner with console




2 seat recliner with console




Single seat


Assemble the Lounges



3 seat recliner with console




2 seat recliner with console




Single seat

Connect the wires.



3 seat recliner with console




2 seat recliner with console




Single seat






3 seat recliner with console



2 seat recliner with console



Single seat



Get the cable under the chair, then connect the sofa with a socket via the cable as left image.

Connect the adaptor with the console.
Then plug the plugs into the wall socket.

Specification

- Rated input for the recliner: AC 100~240V 1.5A
- Rated output for the recliner: 58W
- USB output: 5V 2.1A max
- Rated input for the socket box: AC 240V 10A (On the console of the 3 seat)
- Rated power for the socket box: 2400W (On the console of the 3 seat)

Function Description

- Tap and hold one of the switch button to recliner or close the chair, the other one to lift the headrest up or lay down the headrest.