
TARGET
FURNITURE

CAPRI / SENTOSA EGG CHAIR



PRE-ASSEMBLY PREPARATION

BEFORE YOU START

1. Choose a clean, level, spacious assembly area.
2. Avoid hard surfaces that may damage the product.
3. Check and ensure you have all required contents for complete assembly.
4. Always read the assembly instructions carefully before beginning.
5. The packaging and contents can be a choking hazard, therefore keep out of reach of small children at all time.
6. Do not over tighten bolts as this may damage the thread.



ALLOW 30 MINUTES FOR ASSEMBLY




1 PEOPLE REQUIRED FOR ASSEMBLY

COMPONENTS / HARDWARE

A  1PC ϕ1000×635	B  1PC ϕ50×560	C  1PC 1100×625	D  1PC 950×725×1210
E  1PC 78×37×ϕ7	F  1PC 172×ϕ8	G  1PC 106×ϕ38	H  1PC ϕ16×70
I  1PC 1300×1200×300	1  2PCS M8×60	2  4PCS M8	3  2PCS M8
4  2PCS M8	5  2PCS M8	6  2PCS M8	7  1pc 5MM
8  1pce	**SEE PAGE 3 FOR IMPORTANT SAFETY STEPS**		


STEP 1:

CONNECT PART B TO PART A FOLLOWING THE STEPS SHOWN IN BELOW DIAGRAM.
BOLTS CAN BE TIGHTENED AT THIS POINT.
BE CAREFUL NOT TO OVERTIGHTEN AS THIS MAY DAMAGE THREADS.




STEP 2:

CONNECT PART C TO PART B FOLLOWING THE STEPS SHOWN IN BELOW DIAGRAM.
BOLTS CAN BE TIGHTENED AT THIS POINT.
BE CAREFUL NOT TO OVERTIGHTEN AS THIS MAY DAMAGE THREADS.




STEP 3:

CONNECT PART G, F AND E TO THE HOOK ON PART C AND HANG THE EGG FOLLOWING THE STEPS SHOWN IN BELOW DIAGRAM.




STEP 4:

PLACE CUSHION H IN THE EGG AS SHOWN BELOW.



STEP 5:

ATTACH THE SAFTY STRAP WITH THE POLE.
AND YOUR POD IS READY TO USE



FINISH

IMPORTANT SAFETY INFORMATION

NOTICE:

THIS POD CHAIR IS NOT A SWING AND IF USED INCORRECTLY COULD CAUSE SERIOUS INJURY TO YOURSELF AND OTHERS.

DO NOT USE THIS POD AS A SWING.

DO NOT STAND ON OR INSIDE THE POD.

EITHER COULD RESULT IN THE POD BECOMING UNBALANCED AND OVERTURNING RESULTING IN SERIOUS INJURY TO YOURSELF AND OTHERS.

IT IS RECOMMENDED THE FOLLOWING STEPS BE TAKEN TO AVOID ANY ACCIDENTS.

CARE AND MAINTENANCE

GLASS

•If the glass is chipped or broken, stop using the product and consult the place of purchase
•Do not drop, drag or strike glass
•Do not sit or stand upon the glass surfaces
•Do not place very hot or cold items on the glass unless adequately thick table mats are used to prevent such items coming in contact with the glass
•Do not place heavy objects on glass
•Avoid scratching the glass or using as a chopping surface
•Do not strike the glass with hard or pointed items
•When cleaning the glass panels, use a damp cloth with washing up liquid or soft soap if necessary. Do not use washing powders or any other substances containing abrasives that may potentially scratch the glass

CHAIRS AND STOOLS

•**Do not**:

- Use chair/stool as a ladder
- Climb on the chair/stool
- Stand on the foot-rest of the chair, as this could lead to the stool becoming unbalanced and overturning

WICKER AND TEXTILENE

•Our Resin wicker and Textilene furniture requires very little maintenance to keep it looking like new.
•For daily care and spills, simply wipe clean using a soft, dry cloth.
•To remove dirt and grime, simply rinse with fresh water or periodically clean using a sponge and mild detergent solution as required.
•To protect the finish, avoid the use of abrasive chemicals,
harsh cleaners, rough cleaning pads and polishes.

IN CASE OF DIRECT SUNLIGHT

•To guard against fading, any Outdoor Furniture exposed to direct sunlight or the everyday elements, we recommend the use of outdoor furniture covers.
•For cushions exposed to direct sunlight or the everyday elements, we recommend storage of cushions when not in use.