


ASSEMBLY INSTRUCTION

LV200.D01 - DINING TABLE 180

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have come loose inside carton during shipment. Identify and count all parts and compare with the parts list below.



ASSEMBLY INSTRUCTION :

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior start of assembly.
3. Please follow attached instruction in the same sequence as numbered to assure fast and easy assembly










WARNING !




1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.
3. Two persons are required for assembly.
4. Approximate assembly time : 1/2 hours.
5. Component parts and fittings contained in the box.

Please sort out all parts before you begin to assemble the item.


This is to make sure you always use the correct part .

No.	Component	Q'ty
Ⓐ	 Top panel	1
Ⓑ	 Metal Legs	2
Ⓒ	 Metal Support	4


No.	Hardware list	Q'ty
①	 Bolts M8x20	24
②	 Bolts M6x55	8
③	 Flat washers Ø6x20	8
④	 Flat plastic washers Ø6x20	8

No.	Hardware list	Q'ty
⑤	 Flat washers Ø8x20	8
⑥	 Lock washers Ø8x14	8
⑦	 Allen key K4	1

Step 1



Step 2



Step 3 : Finish

